


FASTIVAL INSTALLATION MANUAL





Structure
Power Poles and its cable
Outside Membrane Bar
Membrane
Outside Membrane
Feet in their box
Weights




Let them lay on the side of the structure














First install the middle support and then screw the bar on both sides






Connect the power poles to the middle joint




Unlock the break



For the structure with 3 side joints, use the connection provided with the poles








Lift the power poles cable to close the structure farter, till it allows the connection of the cables When cables are secured, the powerpole cable can be removed












after this step

The feet should be flat on the ground

structure is well placed









Check the technical sheet to know the necessary ballast


https://www.konligo.com/resources/

INSTRUCTION TO CLOSE




Don't forget to remove all the safety cables before folding the structure and to loosen the straps. Otherwise you might

damage components.



When closing, don't put your hands between the beams



To fold the structure, you don't need power poles. Just lift and pull one side of the structure outward